

# RPP-PVC Polyurethane Gun Foam for PVC

Super low-pressure (with "low-expansion" formula), one-component polyurethane foam with applicator gun.

#### **Product information**



### **Applications**

- Fixing pipes and cables in HVAC systems
- The application of PU foam: installation of windows and doors, filling, sealing, insulation in the construction industry
- Easy fixing of door and window frames timber, metal or PVC
- · Installation of windows and door
- Precise filling and sealing in the wide range of sizes gaps
- Thermal insulation of plumbing and central heating
- · Installation & sealing of window sills
- Thermal insulation of roofing (including flat roofs)
- Filling gaps in the thermal insulation of buildings
- Filling frame structures

#### Features and benefits

- Low Expansion formulation (low growth) enables applications to narrow gaps, guarantees high yield (no wastes) and eliminates the risk of frame deformation
- Low-pressure formulation eliminates risk of frames deformation and ensures proper gaps filling
- Ideal for installation, sealing and soundproofing for PVC profiles
- Excellent sound and thermal insulation properties.
- Cutting time 40 min after apllication
- Excellent adhesion to most materials and substrates used in construction.
- · Resistant to mould and fungi.

#### **Base materials**

Approved for use in:

## Installation guide















- 1. Wear protective gloves. Ensure surfaces are free from dust, dirt or debris.
- 2. Before using, make sure that the can temperature is above zero (optimum  $+20^{\circ}$ C). Application temperature from  $+5^{\circ}$ C up to  $+30^{\circ}$ C.
- 3. Shake can vigorously for 30 seconds to mix properly components.
- 4. Screw gun onto the can. Hold can upside-down during application.
- 5. Moisten surfaces with water prior to application.
- 6. Fill gaps from down to up, zigzag motion, alternating from one wall to the other. Fill gaps to approximately 60 % volume. Max. wide of the gap 3-4 cm. Wider gaps should be applied after hardening of the previous layer. Each layer should be moistened with water using a spray.
- 7. After full curing, cut the excess foam with a knife and protect it from UV exposure by coating with plaster, paint, acrylic or silicone.
- 8. In the event of a stoppage exceeding five minutes duration, wipe the nozzle with cleaner for foam applicator.
- 9. After removing the applicator gun from the can, wipe down the nozzle and gun (internal and external surfaces) using a cleaner.

#### **Technical Data**

Parameter		Value	Methods		
Application temperature	[°C]	+5 ÷ +30			
Can temperature	[°C]	+20			
Efficiency	[dm³]	max. 45			
Colour	-	Light yellow			
Post-expansion	[%]	60			
Skin formation time	[min]	5 ÷ 12	20°C, RH 90%		
Pretreatment time	[min]	45	20°C, RH 90%		
Complete hardening time	[h]	24			
Fire resistance class	-	B3	DIN 4102		
Density	[kg/m <sup>3</sup> ]	19 ± 10	PN-EN ISO 845:2000		
Dimensional stability	[%]	≤3	40°C, RH 95%, 24 hrs		
Water absorption after 24h	[kg/m <sup>3</sup> ]	≤1	PN-EN 1609:1999		
Tensile strength	[kPa]	≥ 100	PN-EN 1607:1999		
Compressive strength	[kPa]	≥ 40	PN-EN 826:1998		
Thermal resistance (upon hardening)	[°C]	-50 ÷ +90			
Thermal conductivity	[W/mK]	0,036			
Preparations solublity	-	Acetone, before hardening	Cleaner RPC-0500		
Soundproofing coefficient	[dB]	61	EN 12354-3		
Volume	[ml]	750			

Parameter		Value		
Shelf life [month]		15		
		upright position in an originally closed container		
	-	the storage temperature: from +5°C to +35°C (room temperature is recommended)		
rage conditions		dry, cool and well-ventilated place away from direct sunlight and other sources heat and ignition		
		storing the product in conditions other than recommended may shorten the life time even by 3 months		

#### Product commercial data

Product Code Colour	Volume [ml]	Quantity [pcs]			Weight [kg]			Bar Codes	
	Cotour	Cotodi Votalile [iiit]	Вох	Outer	Pallet	Вох	Outer	Pallet	Bai Codes
RPP-PVC	Light yellow	750	12	12	672	10.8	10.8	636.5	5906675284064